

## To Measure stroke length of a lever action:

1. With a ruler, measure 3" from the back of the trigger.



2. Mark the 3" position on both lever and receiver



3. With the lever fully opened, measure the distance between the two marks.



4. The SASS Firearms Covenants specify that:  
*“All lever action rifles must have a lever travel distance of not less than 4 1/8 inches.”*

